

Palazzo

Care 16

MAINTENANCE
INSTRUCTIONS FOR
WALLCOVERING
AND PANELS W/
NATURAL FIBERS

Cleaning Code S: Clean only with a water free cleaning solvent. Do not saturate. Do not use water.

- Quickly blot out fresh spills with a white absorbent cloth.
- Spot using a mild pure water-free cleaning solvent or dry cleaning product.
- Pre-test the product in a less visible area before use and, as before, be sure to not over- saturate, allow the area to dry completely and use a clean, white cloth.
- Blot out the solution with dry, clean cloth.
- If the stain persists, rub lightly in a circular motion using a clean part of the cloth. Reverse the circular motion using a clean part of the cloth each time.
- Abrasive rubbing of spots should be avoided, discoloration and delamination may occur.
- Always consult with a professional cleaning service for difficult stains or when overall cleaning is needed.