Carnegie Loop Durable Woven Wallcoverings Installation Instructions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Storage	Rolls of fabric wallcovering should be stored so that a minimum weight rests on each piece. Do not stand on end.
Examination	All wall-coverings must be examined for pattern, color, and quality. Make sure multiple rolls match each other. Carefully inspect wallcovering before cutting, as cut material cannot be returned. DO NOT HANG MORE THAN THREE DROPS without reviewing for shade consistency. Bear in mind that minor shading is to be expected with woven wallcoverings.
Wall Preparation	Walls must be completely smooth. The wall should be prepared with a quality wall-covering primer chosen at the discretion of the installer.
Adhesive	Use a clear wallcovering adhesive at full strength. Adhesives should not be thinned with water or chemical solvents. Allow the adhesive to become tacky before hanging fabric.
Hanging	When possible, all wallcoverings should be installed under adequate lighting. Color uniformity is best evaluated under permanent light conditions. AFTER THREE STRIPS ARE INSTALLED, INSPECT THE WALLCOVERING to ensure that the installer and designer are satisfied with the overall look. Apply the adhesive to the wall (aka "Dry Hang"), and allow tack, per the glue manufacturer's instructions. We recommend table trimming and butting. Use a new blade for each sheet. If the wallcovering tends to curl away from the top or bottom of the wall, prime the top or bottom edges of the wall with adhesive. Straight hang drops consecutively off the bolt. Perfect seams and shading cannot be guaranteed. Shading tends to be optical (depending on lighting at the installation site), and should be carefully monitored throughout the hanging process. If shading or paneling occurs, then reversing the drops may reduce and/or control this issue.
Clean-up	Do not wash seams with water. Any excess adhesive, which comes through at the seams, should be allowed to dry and should then be removed with a dry brush. When removing excess adhesive from the ceiling and the baseboard, protect the fabric from water. DO NOT WET THE FABRIC. If you have any questions concerning the installation of this fabric, please contact your local sales representative or our Rockville Centre, NY office at (516) 678-6770 before proceeding.