
Installation Guide Xorel Artform

Ceiling Vertically Suspended Acoustical Baffles Using Cables



Before Getting Started

Check Your Panels

Make sure you received everything you ordered. Please let us know if you have any questions or concerns by calling 1.800.727.6770 or visiting xorelartform.com.

Prep Your Work Area

Clear the area of all furniture. If the room where the baffles are going to be installed has a hard floor, clean the floor, or cover it in construction paper to protect the panels when laying them face down.

Note

If there are obstructions on the ceiling (water pipes, electrical boxes, etc), the cables can be relocated 1/4" to 1/2" off center.

We recommend having a rendering/layout of the final design on site for reference during installation.

Packaged Components



0 0

Baffles with Pendants Attached Stickers



Pendant with Screw Eyes & Rawl Plugs 2 for each baffle Allen Key & Set Screw 2 screws per baffle




2 for each baffle


Additional Tools Needed

Vertical Spot Laser Wide Field Laser Ceiling Mounting Materials Wirecutters Pliers

Installation Steps




Set a reference line on the floor.




Reference chart within this guide and note the hanging point measurements (E) for the shape and size baffle being installed.

D = distance between each hanging cable (aka center points) E = distance between the end of the baffle and closest hanging cable (aka outer points)




Using either the stickers provided or tape, begin marking the anchor points on the floor using the (E) measurements, directly under the location the baffle will be installed. Repeat until each baffle is accounted for.

Place the vertical spot laser on top of each center point sticker/tape, and mark the anchor points on the ceiling (2 points per baffle).




Once both points have been marked, use measurement (D) to ensure the accuracy of spacing between anchor points. Attach a rawl plug and pendant screw eye to each center point on the ceiling.


Repeat until the all rawl plugs and pendant screw eyes are attached to the ceiling.



Insert one end of the cable into the pendant attached to the ceiling. Secure the cable using the setting screw and allen key.




Insert the end of the cable into the pendants attached to the baffle. Secure the cable using the set screw and allen key.



Set the wide field laser at the C measurement and cut each cable. Reference chart within this guide for the (B) measurement of the shape and size baffle being installed. Calculate the sum of the (B) measurement and desired finished suspended baffle baseline height (A). Once determined (B+A) subtract that number from current ceiling height, this will determine the cut length (C) of the installed cables.

Installation Measurements



| | Panel Width (inches) | D | E | В |
|-------------|----------------------|------|------|-------|
| Circle | 24 (L) | 14 | 5 | 22.25 |
| | 30 (XL) | 18 | 6 | 27.5 |
| | 40 (2XL) | 24 | 8 | 36.5 |
| | 47.5 (3XL) | 28.5 | 9.5 | 43.25 |
| Diamond (H) | 32 (L) | 19 | 6.5 | 13.5 |
| | 40 (XL) | 24 | 8 | 16.75 |
| | 47.5 (2XL) | 28.5 | 9.5 | 19.75 |
| Diamond (V) | 18.5 (L) | 11 | 3.75 | 23 |
| | 23 (XL) | 14 | 4.5 | 29.5 |
| | 27.5 (2XL) | 16.5 | 5.5 | 33.75 |
| Flip | 24 x 16 (L) | 14 | 5 | 16.5 |
| | 24 x 24 (XL) | 14 | 5 | 24.5 |
| | 48 x 16 (2XL) | 29 | 9.5 | 16.5 |
| | 48 x 24 (3XL) | 29 | 9.5 | 24.5 |
| Hex | 24 (L) | 14 | 5 | 19.5 |
| | 32 (XL) | 19 | 6.5 | 25.5 |
| | 40 (2XL) | 24 | 8 | 31.75 |
| | 47.5 (3XL) | 28.5 | 9.5 | 37.5 |
| Ripple | 48 x 16 | 24 | 12 | 16.5 |

Contact Us

Email info@xorelartform.com

Phone 1-800-727-6770