Chroma

Care 3

MAINTENANCE INSTRUCTIONS FOR 100% SYNTHETIC FIBERS AND FILMS

Cleaning Code WS + BC: Clean with mild detergent or shampoo, foam or water-free solvent as desired. Do not saturate with liquid. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned or laundered. Diluted bleach solution can be used, if needed for disinfecting.

- Quickly blot up fresh spills with a dry towel to avoid deep penetration of the stain.
- Pretest a small area before proceeding. To avoid a ring, work with a clean damp cloth from the outside of stain and work inward.
- Use a professional furniture cleaning service for persistent stains and/or when an overall soiled condition has been reached.
- Water-based cleaning agents and foam may be used for cleaning. Mild, water-free solvents can also be used on this fabric. Do not over wet the fabric.
- Up to 20% diluted bleach solution can be used for disinfecting.
- After cleaning, always rinse with fresh water to remove any detergent or cleaning agent residue from the surface of the fabric.
- Please be careful: These instructions are for the fabric only. Some fabric cleaning methods may cause damage to underlying materials used to make the furniture item.