# Carnegie

## Xorel Fragment Emboss - Default Category

#### Care 11

## Carnegie Xorel<sup>®</sup>

# XOREL CLEANING Xorel yarns are non-absorbent; dust and stains cannot penetrate them. Regular maintenance will keep the fabric looking new for many years. Periodic vacuuming will remove dust that may settle between the yarns. Most stains that dry between the yarns or on the surface can be eliminated by wiping the fabric with a cloth moistened with hot tap water. Same stains may require additional treatment. These stains can be cleaned with a variety of water or solvent based cleaners. When using solvent based cleaners on paperbacked Xorel fabric, test on a small area first. Residue from these cleaners must be removed with hot water and a clean sponge. After cleaning, towel dry. Hardened solids can be removed with stiff brush or a sharp-edged instrument without damaging the fabric. However, the brush or sharp instrument should not be used close to seams. Hospital grade disinfectant cleaners can be safely used on Xorel fabrics. Always follow the directions for the specific brand being used as contact times may vary depending on the product. Diluted

Xorel Artform can be cleaned using the same water and/or solvent based cleaners as our standard Xorel fabric offerings, and is bleach cleanable. Be careful not to apply too much pressure or over wet the substrate as it may adversely affect the fabric tension, panel alignment and/or bond.

bleach solution (up to 40%) can also be used on Xorel for disinfecting purposes.

# Carnegie

### Xorel Fragment Emboss - Default Category

#### Care 11

## Carnegie Xorel<sup>®</sup>

# STAIN REMOVAL

In tests conducted at intervals of one hour, one day and seven days, 24 common stains were completely removed by the following procedures.

Adhesives (Clear or Clay based)	Wash with hot water. Towel dry.	Ketchup	Wash with hot water. Use spot remover (Carbona®) then bleach. Towel dry.
Antacid ( <i>Maalox®</i> ) Beer	Wash with hot water. Towel dry. Wash with hot water. Towel dry.	Lipstick	Use pencil eraser, then apply wax stripper (Trewar®). Wash with hot water. Towel dry.
	Wash with a solution of liquid dish detergent (Ivory®) and water. Then apply bleach. Towel dry.	Liquid Soap	Wash with hot water. Towel dry.
Betadine		Milk	Wash with hot water. Towel dry.
Blood	Wash with a solution of liquid dish detergent (Ivory®) and ammonia. Towel dry. Wash with hot water and apply spray xcleaner (Fantastic®). Towel dry.	Mustard	Wash with hot water then apply spray cleaner (Fantastic®). Towel dry.
Butter		Nail Polish (Wet n Wild)	Use nail polish remover with Acetone, then rinse with hot water. Towel dry.
Datter		Nail Polish Remover (with or withou Acetone)	Rinse with hot water. Towel dry. ut
Coffee	Wash with hot water and apply spray cleaner (Fantastic®). Then apply spot remover (Carbona®). Towel dry.		
Cola	Wash with hot water then apply spot remover (Carbona®). Towel dry.	Newsprint	Wash with hot water. Towel dry
Crayon	Use pencil eraser, then apply wax	Pen (Ball-point)	Use pencil eraser wash with hot water. Towel dry.
Clayon	stripper (Trewax®). Wash with hot water. Towel dry.	Salad Dressing	Wash with hot water. Towel dry.
Dirt Gum	Wash with hot water. Towel dry. Use spot remover (Carbona®), then	Shoe Scuffs	Use carpet / upholstery cleaner (Carbona®, Resolve®). Wash with hot water. Towel dry.
	wash with hot water. Towel dry.	Теа	Wash with hot water. Towel dry.
Hair Tonic (Brylcreem®)	Use carpet / upholstery cleaner (Carbona®, Resolve®), then wash with hot water. Towel dry.	Urine Use carpet / upholstery cleaner (Carbona®, Resolve®), then apply vinegar. Wash with hot water. Towel dry.	Use carpet / upholstery cleaner
Hairspray (LaCoupe)	Dab with soap solution, then rinse with hot water. Towel dry.		
Permanent Hair Dye (Clairol	Lightly scrub with bleach. Rinse with water, towel dry.		

Nice'n Easy)