

Pike Print - Upholstery

Care 30

CLEANING MATRIX  
FOR SILICONE AND  
POLYURETHANE BLEND

	Dry Cloth	Soap/Water	Bleach (20% Solution)	Isopropyl Alcohol (70% Solution)	Virex (or equivalent)	CaviWipes
Dirt and Grime		•	•			
Ballpoint Pen				•		
Marker				•		
Oil		•	•			
Mustard		•	•			
Ketchup		•	•			
Chocolate		•	•			
Coffee/Tea		•	•			
Salad Dressing		•	•			
Blood		•	•		•	•
Urine		•	•		•	•
Betadine		•	•		•	•
Denim Dye		•		•		
Abaya Dye						

## Pike Print - Upholstery

---

### Care 30

#### MAINTENANCE INSTRUCTIONS FOR SILICONE AND POLYURETHANE BLEND

#### Cleaning Code WS + BC

Clean with mild detergent or shampoo, foam or water-free solvent as desired. Do not saturate with liquid. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned or laundered. Diluted bleach solution can be used, if needed for disinfecting.

- Quickly blot up fresh spills with a dry towel to avoid deep penetration of the stain.
- Pretest a small area before proceeding. To avoid a ring, work with a clean damp cloth from the outside of stain and work inward.
- Use a professional furniture cleaning service for persistent stains and/or when an overall soiled condition has been reached.
- Water-based cleaning agents and foam may be used for cleaning. Mild, water-free solvents can also be used on this fabric. Do not over wet the fabric.
- Ink Marks / Graffiti (Ball Point Pen, Permanent Marker)  
Rub the affected area with a dry soft cloth with firm pressure. If some stain is still present spray it with a 70% dilution of isopropyl alcohol and water and wipe. Rinse with fresh water and wipe dry.
- Denim Dye Transfer  
This material is designed to withstand the transfer of most types of Indigo Dye. In the case that faint dye transfer is visible, this can typically be removed with 70% dilution of isopropyl alcohol, and 409 cleaner or equivalent.  
\*Note: Removal of ink and /or indigo dye, particularly from wet jeans, may vary depending on the type of denim. While this material offers excellent protection, full removal is not guaranteed.
- Up to 20% diluted bleach solution common hospital grade disinfectant cleaners i.e. Virex, Caviwipes, Oxycide, etc. can be used for disinfecting.
- After cleaning, always rinse with fresh water to remove any detergent or cleaning agent residue from the surface of the fabric.
- Please be careful: These instructions are for the fabric only. Some fabric cleaning methods may cause damage to underlying materials used to make the furniture item.