Carnegie

Xorel Striee

Carnegie Xorel[®] Care 11 XOREL CLEANING Xorel yarns are non-absorbent; dust and stains cannot penetrate them. Regular maintenance will INSTRUCTIONS keep the fabric looking new for many years. Periodic vacuuming will remove dust that may settle between the yarns. Most stains that dry between the yarns or on the surface can be eliminated by wiping the fabric with a cloth moistened with hot tap water. Same stains may require additional treatment. These stains can be cleaned with a variety of water or solvent based cleaners. When using solvent based cleaners on paperbacked Xorel fabric, test on a small area first. Residue from these cleaners must be removed with hot water and a clean sponge. After cleaning, towel dry. Hardened solids can be removed with stiff brush or a sharp-edged instrument without damaging the fabric. However, the brush or sharp instrument should not be used close to seams. Hospital grade disinfectant cleaners can be safely used on Xorel fabrics. Always follow the directions for the specific brand being used as contact times may vary depending on the product. Diluted bleach solution (up to 40%) can also be used on Xorel for disinfecting purposes. Xorel Artform can be cleaned using the same water and/or solvent based cleaners as our standard

Xorel Artform can be cleaned using the same water and/or solvent based cleaners as our standard Xorel fabric offerings, and is bleach cleanable. Be careful not to apply too much pressure or over wet the substrate as it may adversely affect the fabric tension, panel alignment and/or bond.

Carnegie

Xorel Striee

Care 11

Carnegie Xorel[°]

STAIN REMOVAL

In tests conducted at intervals of one hour, one day and seven days, 24 common stains were completely removed by the following procedures.

Adhesives (Clear or Clay based)	Wash with hot water. Towel dry.	Ketchu
Antacid (Maalox®)	Wash with hot water. Towel dry.	Lipstic
Beer	Wash with hot water. Towel dry.	
Betadine	Wash with a solution of liquid dish detergent (Ivory®) and water. Then apply bleach. Towel dry.	Liquid Milk
Blood	Wash with a solution of liquid dish detergent (Ivory®) and ammonia. Towel dry.	Mustar Nail Pc
Butter	Wash with hot water and apply spray xcleaner (Fantastic®). Towel dry.	(Wet n Nail Pc
Coffee	Wash with hot water and apply spray cleaner (Fantastic®). Then apply spot remover (Carbona®). Towel dry.	Remov (with o Acetor
Cola	Wash with hot water then apply spot remover (Carbona®). Towel dry.	Newsp Pen
Crayon	Use pencil eraser, then apply wax stripper (Trewax®). Wash with hot water. Towel dry.	(Ball-po Salad Dressir
Dirt	Wash with hot water. Towel dry.	Shoe S
Gum	Use spot remover (Carbona®), then wash with hot water. Towel dry.	
Hair Tonic (Brylcreem®)	Use carpet / upholstery cleaner (Carbona®, Resolve®), then wash with hot water. Towel dry.	Tea Urine
Hairspray (LaCoupe)	Dab with soap solution, then rinse with hot water. Towel dry.	
Permanent Hair Dye (Clairol	Lightly scrub with bleach. Rinse with water, towel dry.	

Nice'n Easy)

Ketchup	Wash with hot water. Use spot remover (Carbona®) then bleach. Towel dry.
lipstick	Use pencil eraser, then apply wax stripper (Trewar®). Wash with hot water. Towel dry.
iquid Soap	Wash with hot water. Towel dry.
Vilk	Wash with hot water. Towel dry.
Mustard	Wash with hot water then apply spray cleaner (Fantastic®). Towel dry.
Nail Polish Wet n Wild)	Use nail polish remover with Acetone, then rinse with hot water. Towel dry.
Nail Polish Remover with or withou Acetone)	Rinse with hot water. Towel dry. t
Newsprint	Wash with hot water. Towel dry
Pen Ball-point)	Use pencil eraser wash with hot water. Towel dry.
Salad Dressing	Wash with hot water. Towel dry.
Shoe Scuffs	Use carpet / upholstery cleaner (Carbona®, Resolve®). Wash with hot water. Towel dry.
Геа	Wash with hot water. Towel dry.
Jrine	Use carpet / upholstery cleaner (Carbona®, Resolve®), then apply vinegar. Wash with hot water. Towel dry.

Maintenance Instructions